

Ultrasonic Flowmeter

Flowmax[®] 400i



Flowmax 400i is a flow meter calculating the volume flow of liquids. Based on the ultrasonic technology Flowmax is able to measure conductive and non-conductive liquids contactfree. Flowmax has no moving parts and is absolutely free of wear. The design of the pipe minimizes dead space over the whole geometry.

All parts having contact to the medium are PFA (New Teflon). Thanks to its technical properties Flowmax is able to measure all kinds of liquids like: DI-Water, Body care liquids, Cosmetics, liquid food, and also aggressive and/or toxic acids and alkalis. Flowmax is characterized by its high measurement accuracy and repeatability. Empty pipe detection is integrated. Optionally Flowmax have a PID controller function. The calculated flow is provided with a response rate of a few milliseconds on the outputs.

Flowmax has by default a preset quantity counter. The start signal can optionally be fed from the outside. A control signal for activation of the pump or valve control is also standard.

Flowmax 400i is very good for operation with piston diaphragm and peristaltic pumps.

Housing


Material	pipe	PFA (Perfluoralkoxy)			
	electronics	PP (Polypropylene)			
	nut	PVDF (Polyvinylidene fluoride) or PFA			
		Optional, NPT Adapter (Flare to NPT), PFA			
Protection class		IP65			
Medium temperature [°C]		0...60			
Measuring range [l/min]		0.03/0.09-6	0.3-24	0.9-60	1.2-120
Nominal diameter [DN]		7	10	15	20
Nominal pressure		PN6	PN6	PN6	PN6
Process connection					
Connection flare or NPT thread		3/8"	1/2"	3/4"	1"
Dimensions L/W/H [mm]		209/120/79	209/120/79	209/120/82	209/120/92
Weight [kg]		1.3	1.3	1.3	1.6

Electronics

Power supply	24VDC, ca. 3.6W
Electrical connection	5 or 8-pin plug, alternative 10-core teflon-coated cable, length 5m
Input	1 digital input, usable for dosing start
Outputs	2 digital outputs, configurable as pulse output or empty pipe alarm, Current output configurable 0/4-20mA, RS485-data interface.
Max. error of measurement	± 2% o.r. ± 0.15% f.s. (o.r. = of reading, f.s. = full scale) option ± 1% o.r. ± 0.15% f.s. Reference conditions (VDI/VDE 2642)
Repeatability	≤ 0.5%

All flow meter parameters are freely configurable by using FlowCon. FlowCon is not part of the delivery of Flowmax 400i. It can be ordered separately.

The variety of outputs / input depends on the plug selection.



Example: Measuring points of a calibrated Flowmax in error graph according definitions

Further information:

MIB GmbH

Bahnhofstr. 35, D-79206 Breisach
Tel. 0049 / (0) 7667 – 20 777 90
Fax: 0049 / (0) 7667 – 20 777 99
Mail: info@mib-gmbh.com
Web: www.flowmax.de

Technical subjects to be changed!